

ISI-CEFL10V

Ceiling Flush Mount Passive Infra Red (PIR) Occupancy Detector & Photocell

Input: 100-240 Vac 50/60Hz



PLEASE READ THESE INSTRUCTIONS BEFORE INSTALLING THE PRODUCT

NOTE: ISI-CEFL10V is only compatible to work with DANLERS enabled app.

This flush mounted ISI-CEFL10V is suitable for easy mounting through a 73/75mm diameter hole into a ceiling void which is at least 78mm deep. Configurable for any room occupancy style, via the free to download DANLERS APP on Google Play or Apple APP Store.

INSTALLATION

To be installed by a competent person with reference to BS 7671 or equivalent local standards. If in doubt consult a qualified electrician.

- Plan where the ISI-CEFL10V is to be located (see diagram 1). Switch off supply and check for hidden cables and pipes. Make a 73/75mm diameter hole through a standard ceiling board.
- The ISI-CEFL10V should be connected as shown in diagram 2:
 - L - Live in. N - Neutral in. + & - Control line (polarity dependent)
- Ensure both springs are fitted to the moulding in the correct orientation (see diagram 3).
- Push the ISI-CEFL10V into the ceiling void, making reference to diagram 4.

OPERATION

To check the operation of the ISI-CEFL10V:

- Turn on the supply then after 20 seconds if the sensor has recognised movement of a person within its zone of detection the integral red LED on ISI-CEFL10V will stay illuminated for 4 seconds before the red LED turns off.
- Thereafter, every time movement is detected by ISI-CEFL10V the integral red LED will stay illuminated for 4 seconds.

The control also features adjustable time out (time lag) control and daylight threshold control which are configured by the DANLERS APP.

PRECAUTIONS






- Do not place the ISI-CEFL10V near heat sources, fans or in ventilated ceiling voids.
- Do not place close to, or positioned such that, any light source points directly into the ISI-CEFL10V.
- Ensure wires and cables are securely held within the connection terminals.
- The ISI-CEFL10V should be protected by a 5 or 6 Ampere mcb or fuse.
- Disconnect the ISI-CEFL10V from the circuit before performing insulation testing of the wiring circuit.**

5 YEAR WARRANTY

ISI-CEFL10V comes with a 5 year warranty from the date of manufacture and is CE marked.

TECHNICAL DETAILS

INPUT	
Voltage:	100 - 240Vac
Frequency:	50/60Hz
Max. mains current:	20mA
Standby current:	14mA
OUTPUT	
Output:	0-10VDC
Max. Current:	40mA (maximum 20 ballast)
RADIO TRANSCEIVER	
Operating frequencies:	2.4... 2,480 GHz
Max. output power:	+4 dBm
LUX PARAMETERS	
Range:	5 - 2000 lux
OPERATING CONDITIONS	
Note: The temperature difference between the detection target and the background must be at least 4 °C.	
Ambient temperature:	-20... +40 °C (lout 20mA)
Storage temperature:	-25... +75 °C
Max. relative humidity:	0... 80%, non cond.
CONNECTORS	
Terminal block Wire size:	0,5mm ² - 2,5mm ² solid or stranded
Wire strip length:	6-7mm
Tightening torque:	0,4 Nm/4 Kgf.cm
MECHANICAL DATA	
Dimensions:	79mm x 85mm x 85mm
Weight:	97g (unpacked)
Degree of protection:	IP40
Protection class:	Basic protection
Material (casing)	Flame-retardant polycarbonate
Finish / Colour	Matt /White (RAL 9003)
CONFORMITY AND STANDARDS	
EMC emission: EN 301 489-1 V2.2.0, EN 301 489-17 V3.1.1, EN 55032: 2015, EN61000-3-2: 2014, EN61000-3-3: 2013	
EMC immunity: EN 301 489-1 V2.2.0, EN 301 489-17 V3.1.1	
Environment: Complies with WEEE and RoHS directives	



DANLERS Limited, Vincients Road, CHIPPENHAM, Wiltshire, SN14 6NQ, UK.
Telephone: +44 (0)1249 443377 Fax: +44 (0)1249 443388 E-mail: sales@danlers.co.uk
www.danlers.co.uk

Company Registered Number 2570169 VAT Registration Number 543 5491 38

30/03/2022

DAT0152 ISI-CEFL10V

DANLERS