# **CBU-CESR10V**

# Ceiling Surface Mount Passive Infra Red (PIR) Occupancy Detector & Photocell

Input: 100-240 Vac 50/60Hz

CASAMBI

PLEASE READ THESE INSTRUCTIONS BEFORE INSTALLING THE PRODUCT NOTE: CBU-CESR10V is only compatible to work with Casambi enabled app.

This CBU-CESR10V Lighting Control can be mounted directly onto solid ceilings or onto a range of different mounting boxes. Configurable for any room occupancy style, via the Casambi APP on Google Play or Apple APP Store.

#### INSTALLATION

To be installed by a competent person with reference to BS 7671 or equivalent local standards. If in doubt consult a qualified electrician.

- Plan where the CBU-CESR10V is to be located (see diagram 1). Switch off supply and check for hidden cables and pipes.
- The CBU-CESR10V should be connected as shown in diagrams 2 and 3:
  - Live in.
  - Ν Neutral in.
  - Control line (polarity dependent)
  - Control line (polarity dependent)
- Knockout or drill the appropriate holes on the mounting plate for attaching the plate to the ceiling or back box (if applicable). Feed cables through the appropriate (side or rear) entry hole. Screw the back mounting plate to the ceiling or back box via the mounting holes. Wire the cables into the sensor head block terminal. Push the sensor head onto the mounting plate and align the side clips with the slots on the sensor heads.

### **OPERATION**

To check the operation of the CBU-CESR10V:

- Turn on the supply then after 20 seconds if the sensor has recognised movement of a person within its zone of detection the integral red LED on CBU-CESR10V will stay illuminated for 4 seconds before the red LED turns off.
- · Thereafter, every time movement is detected by CBU-CESR10V the integral red LED will stay illuminated for 4 seconds.

The control also features adjustable time out (time lag) control and daylight threshold control which are configured by the Casambi APP.

#### **PRECAUTIONS**

- Do not place the CBU-CESR10V near heat sources, fans or in ventilated ceiling voids.
- Do not place close to, or positioned such that, any light source points directly into the CBU-CESR10V.
- · Ensure wires and cables are securely held within the connection terminals.
- The CBU-CESR10V should be protected by a 6 Ampere mcb or fuse.
- Disconnect the CBU-CESR10V from the circuit before performing insulation testing of the wiring circuit.

#### **TECHNICAL DETAILS**

INPUT	
Voltage:	100 - 240Vac
Frequency:	50/60Hz
Max. mains current:	20mA
Standby current:	18mA
OUTPUT	
Output:	0-10VDC
Output Current:	40mA (maximum 20 ballasts)
RADIO TRANSCEIVER	
Operating frequencies:	2.4 2,483 GHz
Max. output power:	+4 dBm
LUX PARAMETERS	
Range:	5 - 2000 lux

#### **OPERATING CONDITIONS**

Note: The temperature difference between the detection target and the background must be at least 4 °C.

Ambient temperature:	-20 +40 °C (lout 20mA)
Storage temperature:	-25 +75 °C
Max. relative humidity:	0 80%, non cond.
CONNECTORS	

Terminal block Wire size:	0.5mm <sup>2</sup> - 2.5mm <sup>2</sup> solid or stranded
Wire strip length:	6-7mm
Tightening torque:	0,4 Nm/4 Kgf.cm

MECHANICAL DATA	
Dimensions:	49mm x 91mm x 91mm
Weight:	98g (unpacked)
Degree of protection:	IP20
Protection class:	Built-in Class 2
Material (casing)	Flame-retardant polycarbonate
Finish / Colour	Matt (Mhite (BAL 9003)

#### CONFORMITY AND STANDARDS

### EMC emission:

EN 301 489-1 V2.2.0, EN 301 489-17 V3.1.1, EN 55032: 2015, EN61000-3-2: 2014, EN61000-3-3: 2013

**EMC immunity:** EN 301 489-1 V2.2.0, EN 301 489-17 V3.1.1

Complies with WEEE and RoHS directives


## **5 YEAR WARRANTY**

CBU-CESR10V comes with a 5 year warranty from the date of manufacture and is CE marked.














DIAGRAM 1





DANLERS Limited, Vincients Road, CHIPPENHAM, Wiltshire, SN14 6NQ, UK. Telephone: +44 (0)1249 443377 Fax: +44 (0)1249 443388 E-mail: sales@danlers.co.uk www.danlers.co.uk